



























3 SEATER SWING CHAIR

Instruction Manual



NO.	PICTURES OF PARTS	QUANTITY	Code	PICTURES OF PARTS	QUANTITY
1		1	A		2
2		1	B		1 + 1
3		2	C		2
4		2	D		3
5		2	E		6
6		1	F		8
7		1	G		4
8		2	H		2
9		1	I		4
10		2	J		27
11		2	K		4
12		1	L		27
13		1	M		27

Instruction Manual

Instruction Manual

To assemble the swing you need at least two people. Tools are not included in the package. Before assembly, please check all parts are present and not damaged.

1. For the construction of the swing you will need to find a flat, hard and even surface.
2. Only use swing on a flat surface and keep away from fire and inflammable objects.
3. When using swing, please carefully note the following advice:
 - a) Risk of injury. Don't put arms and legs between seating area and frame of the swing
 - b) Don't put any objects directly in front or behind the swing.
 - c) Excessive swinging may cause the swing to collapse with risk of injuries.
4. Maximum load 400 pounds.
5. Only let children use swing under adult supervision..
6. Occasionally check swing and should you find any loose screws, tighten up immediately.
7. Cover up the swing during wet and windy weather.
8. This swing is not suitable for the winter. Dismantle in the autumn and move to a dry sheltered place.

